XMODS® Wheel Upgrade Kit

60-437

Thank you for purchasing your wheel upgrade kit from ***RadioShack***. Please read this user's guide before installing, setting up, and using your new product.

Customize your vehicle with high performance wheels. This kit includes three kinds of custom wheels, 12 lug nuts, and one lug nut wrench, plus two front disc brakes and two rear disk brakes (first generation XMODS only). Each wheel set includes four (4) wheels with tires. Before installing, turn off your vehicle and controller, and detach the car body.

1. Use the supplied lug nut wrench to detach the lug nuts from each wheel.
2. Remove a wheel from the axle.
3. Place a tire on the new wheel.

   Note: *You can use the tires that come with your starter kit. If you own the first generation Mustang or Camaro or 65 Mustang, use the tires included in this kit, since these car models have different tire diameters.*
4. Snap the disc brakes onto the axle. The larger brakes go on the front axle, the smaller brakes go on the rear axle.

   Note: *If your car is one of the EVO XMODS series, you cannot use the disk brakes supplied with this kit. Use the ones supplied with your starter kit.*
5. Align the flat side of the wheel with the flat side of the axle and slide the wheel onto the same axle.
6. Screw the lug nut onto the axle and tighten with the supplied lug nut wrench.
7. Repeat steps 2-6 for each wheel.

   Note: *If your car is a Lancer and Firebird, wheel spacers are attached to your wheels. When disassembling, be sure not to lose them.*



① *to* ③



④ *to* ⑥

Limited Warranty

This product is warranted by ***RadioShack*** against manufacturing defects in material and workmanship under normal use for ninety (90) days from the date of purchase from ***RadioShack*** company-owned stores and authorized ***RadioShack*** franchisees and dealers. EXCEPT AS PROVIDED HEREIN, ***RadioShack*** MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, ***RadioShack*** SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF ***RadioShack*** HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the ***RadioShack*** sales receipt as proof of purchase date to any ***RadioShack*** store. ***RadioShack*** will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of ***RadioShack***. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a ***RadioShack*** Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations
300 RadioShack Circle, Fort Worth, TX 76102 12/99

www.radioshack.com

www.xmodsRC.com

©2008 **RadioShack** Corporation
All Rights Reserved.
XMODS is a registered trademark used by **RadioShack** Corporation.

08A08
60-437
INS-3271-US-00
Printed in China